



Dell Inspiron B130 Battery Replacement

This guide will tell and show you how to replace the battery for the Dell Inspiron B130. This will be a prerequisite guide for most if not all of the other replacement guides on this device page.


Written By: Owen Sullivan



INTRODUCTION

Use this guide to replace a broken battery. Your battery may be broken if your computer will only turn on when it is connected to the charger, but please refer to our [Troubleshooting Guide](#) for more information.




Step 1 — Battery



⚠ First, make sure your computer is turned off.

- Flip your computer over and you can see the battery.

Step 2



- Push the tab from the battery, downwards to unlock the battery.
- The tab should be in the position next to the unlocked indicator.

Step 3



- Now, push the other tab (the one right under the battery) from right to left.
- Now the battery will be loose; lift the battery up and out of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 09:24:09 AM.